



DE Montageanleitung  
GB Assembly Instructions  
FR Instructions de montage  
ES Instrucciones de montaje  
IT Istruzioni per il montaggio  
NL Montage-instructie


PT Instruções de montagem  
DK Montagevejledning  
SE Monteringsanvisning  
PL Instrukcja montażu  
GR Οδηγία μοντάζ  
CZ Návod k montáži

SI Navodilo za montažo  
SK Návod na montáž  
HU Szerelési útmutató  
RO Instrucțiuni de montaj  
TR Montaj kılavuzu





Ax4

0 1 2 3 4 5




A x4

2



1



1

1

